



Cal 9900
 Controller Set-
 Up
 For Delta T
 Water Units
 Revised
 7/15/2005

∧ ∇ changes values

SECURITY: To disable security lockouts, remove the cover containing the 4 setting control buttons. There is a jumper in the middle. If it is protected, move it to the next adjoining pin to enable programming. To protect, move it back.

PROGRAMMING: To enter programming, depress the P button. The display should begin flashing the set of numbers to the right of the decimal which indicates the function. The value associated with that function is to the left of the decimal. Pressing the * key will toggle the flashing display from the right to the left. The flashing number is the one to adjust the value. Adjust the values with the ∧ ∇ keys. Set the value and press the * key to return to the function selection, which should now be flashing. Press the ∧ key to advance to the next function and continue to set the values. When finished, depress the P key to return to the operation mode.

Operation: To change the process temperature, hold the * key and press the ∧ ∇ keys to adjust temperature.

Menus

Value	Function	Value	Function	Value	Function	*For 23 you will accept the value it suggests. It cannot be changed Note: on 24 you need to hold the * key down while changing value
0	0	13	11	1	22	
0	1	0	12	* 6 or 8 ?	23	
5	2	0	13	250	24	
0	3	0	14	0	25	
3	4	0	15			
3	5	1	16			
2	6	0	17			
0	7	0	18			
8	8	7	19			
0	9	0	20			
10	10	0	21			