



**Omron E5CN
 Controller
 Set-Up
 MT-500
 For Delta T
 Chiller Units
 Revised
 8/14/2008
 (Controller is smaller
 than pictured)**

Note: Unlock¹ the controller by performing the Security Level Unlock¹ first.

Set Security Level values to 0 or off to unlock¹ which will allow you to make changes in the Initial Settings or Adjustment Level. You may then go to Initial Setting or Adjustment Level by following the steps in each section. Reset to the default Security Level settings when finished with the Initial Setting Level and Adjustment Level. This will protect the controller from unauthorized or unwanted changes to these settings. The Adjustment Level is determined by the Initial Setting. Do Initial Setting first.

<u>Initial Setting Level - Before Adjustment Level</u>	<u>Adjustment Level - After Initial Setting</u>	<u>Security Level (Default)</u>																																												
<p>Press Level Key 3 seconds to enter Initial Setting menu. display reads CN-t</p> <p>Enter the value shown in the right column below. To change value, press the up or down arrow. Press the mode key to advance to the next function. When finished with all functions, exit by pressing the Level Key 1 second</p> <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;"><i>Function</i></th> <th style="text-align: left;"><i>Value</i></th> </tr> </thead> <tbody> <tr><td>Cn-t</td><td>8</td></tr> <tr><td>d-U</td><td>f</td></tr> <tr><td>SL-H</td><td>70</td></tr> <tr><td>SL-L</td><td>42</td></tr> <tr><td>Cntl</td><td>Pid</td></tr> <tr><td>5-HC</td><td>std</td></tr> <tr><td>ST</td><td>on</td></tr> <tr><td>CP</td><td>8</td></tr> <tr><td>6rEu</td><td>R</td></tr> <tr><td>Alt1</td><td>2</td></tr> <tr><td>* Alt2</td><td>0</td></tr> <tr><td>* AMoV</td><td>0</td></tr> </tbody> </table>	<i>Function</i>	<i>Value</i>	Cn-t	8	d-U	f	SL-H	70	SL-L	42	Cntl	Pid	5-HC	std	ST	on	CP	8	6rEu	R	Alt1	2	* Alt2	0	* AMoV	0	<p>Press Level key < 1 second to enter Adjustment Level menu. Display reads L.AdJ</p> <p>Press mode key, enter value shown in the right column below. To change value, press the up or down arrow. Press mode key to advance to the next function. When finished with all functions, exit by pressing Level Key < 1 second</p> <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;"><i>Function</i></th> <th style="text-align: left;"><i>Value</i></th> </tr> </thead> <tbody> <tr><td>P</td><td>.5</td></tr> <tr><td>I</td><td>20</td></tr> <tr><td>d</td><td>5</td></tr> </tbody> </table>	<i>Function</i>	<i>Value</i>	P	.5	I	20	d	5	<p>Press Level and Mode keys simultaneously 3 seconds to enter security. Display reads oAPt Press V / ^ to change values</p> <p>Press the mode key to advance to the next function. When finished, press level and mode key 3 seconds to exit security. The settings below are the final settings. If you are changing other values you will need to unlock by following steps below.</p> <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;"><i>Function</i></th> <th style="text-align: left;"><i>Value</i></th> </tr> </thead> <tbody> <tr><td>oAPt</td><td>2</td></tr> <tr><td>LCPt</td><td>2</td></tr> <tr><td>WtPt</td><td>off</td></tr> <tr><td>PRLP</td><td>0</td></tr> </tbody> </table> <p>¹ TO UNLOCK</p> <p>Set above values to 0 or off to unlock which will allow you to make changes in the Initial Settings or Adjustment Level. You may now go to Initial Setting or Adjustment Level by following the steps in each section. Reset to the above settings when finished with Initial Setting Level and Adjustment Level to protect from unauthorized or unwanted changes to these settings.</p>	<i>Function</i>	<i>Value</i>	oAPt	2	LCPt	2	WtPt	off	PRLP	0
<i>Function</i>	<i>Value</i>																																													
Cn-t	8																																													
d-U	f																																													
SL-H	70																																													
SL-L	42																																													
Cntl	Pid																																													
5-HC	std																																													
ST	on																																													
CP	8																																													
6rEu	R																																													
Alt1	2																																													
* Alt2	0																																													
* AMoV	0																																													
<i>Function</i>	<i>Value</i>																																													
P	.5																																													
I	20																																													
d	5																																													
<i>Function</i>	<i>Value</i>																																													
oAPt	2																																													
LCPt	2																																													
WtPt	off																																													
PRLP	0																																													
<p>Power On Alarm set point = -2</p>		<p>* may not be on all models</p>																																												